



ANSI FL 1 Standard



FLOOD LIGHT - HIGH		500 Lumens	24 M	4 H
FLOOD LIGHT - MID		175 Lumens	15 M	9½ H
FLOOD LIGHT - LOW		15 Lumens	4 M	97 H
FLASHLIGHT - HIGH		300 Lumens	100 M	5½ H
FLASHLIGHT - LOW		70 Lumens	44 M	27 H

OPERATION

Floodlight:- High > Medium > Low > Off

Flashlight:- High > Low > Off

[When ON in either Flashlight or Floodlight, press and HOLD the button to switch to the other mode]

[If left in any mode for over 3 seconds, the next press will turn off]

CHARGING

1. Only use a 5V USB-C cable (max 1A).
2. Lift the charging port cover on the side of the light.
3. Plug the USB-C end of the cable into the charge port.
4. Plug the USB end of the cable into a USB charging port (do not exceed 5V 1A charging input or damage may occur).
5. Charge Time: 3½ hours

(PRODUCT CAN BE USED WHILE RECHARGING)

****Warranty void if not used with the specified chargers****

FEATURES

- High-power 500 lumen white 6500k COB LED
- Additional 300 lumen 6500k white Cree® LED flashlight
- Super tough copolymer construction
- Glow-in-the-dark strip around reflector for extra visibility
- 180° Rotating handle/stand with carabiner snap hook
- Strong magnets within the handle
- IPX5 water resistant
- USB-C charging - 3½ hours charge time
- 1m high quality USB-C charging cable included
- Upgraded LG® 2600mAh battery with increased runtimes

BATTERY - 3.7v 2600mAh Li-ion Rechargeable Battery

WEIGHT - 180g

DIMENSIONS - folded 55 x 123 x 32mm
extended 55 x 215 x 32mm



ADVICE & IMPORTANT INFORMATION!

LEDs will become warm/hot when switched on; do not touch and never place LEDs face down on any surface – risk of fire!

Do not look directly at the LED. Do not operate in direct sunlight or extreme temperature conditions (below -20°C or above 60°C).

Do not use the device if there is any visible damage to the housing, charge port or cable. Take care when using a USB plug adaptor, check for any damage. DO NOT exceed 5V 1A output or damage may occur to the battery.

The rechargeable battery will reach full performance after a few complete charging and discharging cycles.

To keep the rechargeable battery in optimum condition, it should be recharged every 3-6 months, especially if it is not being used for a long period of time. Always fully charge batteries before storage.

Always protect batteries from heat, intense sunlight, fire, water and moisture – danger of explosion!

If a battery is damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact occurs, rinse thoroughly with water. If irritation persists, seek

medical advice. Seek immediate medical assistance if lithium battery fluid comes into contact with the eyes.

Children under 12 years of age should only use the product under adult supervision.

Do not open, disassemble or attempt to modify the product; this will void the warranty and can be dangerous. Improper use or modification is not covered under the warranty.

Take care not to let the lenses come into contact with hard/sharp objects, damage/scratches to the lenses will affect light output.

This product is water resistant to IPX5 – DO NOT SUBMERGE. If the product has been subjected to excessive moisture/water the warranty may be void.

This product has a 1 year standard warranty (or extended to 2 years once registered online at WWW.UNILITE.CO.UK) against manufacturing faults and defects. It does not cover normal wear and tear, modifications, accidental damage or poor maintenance. Unilite warranties do not cover battery leaks or the use of incorrect chargers and cables that can damage batteries.

Do not dispose of this device in normal household waste. It must be disposed of via an authorised electrical appliance disposal centre or at your local waste disposal unit.

Please re-use or recycle packaging where possible.

Keep these instructions for future reference or for subsequent possessors.

